

Product Overview

The X & R Running Tools are used to set model X, XN, R, RN and RQ Lock Mandrels in their respective landing nipples.

The X & R Running Tool can be set up to operate in either **selective or non-selective mode**.

- **Selective Mode:** The lock mandrel can be run through several landing nipples of the same size and type before selecting the desired nipple for setting.
- **Non-Selective Mode:** The lock mandrel locates the first corresponding nipple.

Key Features

- **Multi-model compatibility:** Designed for setting X, XN, R, RN, and RQ Lock Mandrels.
- **Selective operation:** Allows the lock mandrel to pass through multiple landing nipples of the same size and type before selecting the desired nipple.
- **Non-selective operation:** Locates and sets in the **first corresponding landing nipple** encountered.
- **Multiple size options:** Available in sizes ranging from **1.720 to 4.500** in maximum O.D.

Technical Data

Max. O.D. (in)	To Suit Nipple Bore (in)	F/N O.D. (in)	Top Connection
1.720	1.875	1.375	15/16-10 UN
2.171	2.313	1.750	15/16-10 UN
2.687	2.750	2.313	1-1/16-10 UN
2.843	2.875	2.313	1-1/16-10 UN
3.250	3.313	2.313	1-1/16-10 UN
3.750	3.813	2.313	1-1/16-10 UN
4.500	4.562	3.125	1-1/16-10 UN

